

B-310S Series Mini Contour Probes

Smallest of the Small



The **B-310S Contour Probe** is a lightweight (6 lbs.) Magnetic Inspection Yoke designed to perform magnetic particle inspections quickly and reliably, and with greater versatility. The overall length of the unit is only 7.25".

The **B-310S Mini Contour Probe** provides great flexibility and reduced size.

- Units are available in 230 & 42-48 VAC
- 230 VAC, 42 VAC and 48 VAC may be CE certified
- One year repair/replacement guarantee



The reversible strain-relief feature allows the power cord to enter from the rear or top of the unit permitting greater access to small work areas.

As with all Parker Contour Probes, the **B-310S** has fully adjustable legs permitting the AC magnetic field to be applied to the precise area of inspection.

SPECIFICATIONS

	B-310S	B-142
Physical	7.25 L x 7.75 H x 2.125 W	
Line Voltage Single Phase	230 VAC 50/60 Hz	42-48 VAC 50/60 Hz
Line Current	3 A	7.5 A
Duty Cycle	2 minutes on – 2 minutes off	
Weight	6 lb (2.73 Kg)	
Construction	Polyurethane-filled glass/nylon housing 10 foot / 3 wire power cord	
Span	0-9 in. across poles	