



**Tec-line**

### ► **New econoscope**

The new LED econoscope is characterised by an excellent image quality, very bright illumination, compact design and use independent of mains and light guide at a favourable price.

A very bright miniature LED on the lens illuminates even the darkest corner. Due to its adjustable brightness, the light intensity can be adapted easily to different applications. A powerful rechargeable lithium-ion battery allows using it without having to connect it to the mains.

As all HSW borescopes, the device can be combined with the HSW video kit to obtain a fully-fledged video borescopes.

### **Technical details**

Diameter:	5 mm and 9mm
Effective length:	350 mm and 275mm (9mmVersion)
Direction of view:	90°
Field of view:	90°
Brightness:	adjustable
LED:	1W
Rechargeable battery:	lithium-ion



Henke-Sass, Wolf GmbH  
Eilbergraben 1  
76532 Sulzlingen / Germany  
Phone: +49(0)7462/9466-270  
Fax: +49(0)7462/9466-3387  
www.henkesasswolf.de  
garnier@hswwolf@henkesasswolf.de

